



Full-Span Landing, Configuration 31
Slat ds=30 deg, gs/c=0.015, hs/c=0.015
Flap df=30 deg, gf/c=0.010, of/c=0.005

	Run	CONF	MMODREF	RNMODREF		
○	RUN137	31	0.150918	3.60029	CL_UN	vs ALPHA_UN
○	RUN137	31	0.150918	3.60029	CL	vs ALPHA
□	RUN138	31	0.149903	8.63004	CL_UN	vs ALPHA_UN
□	RUN138	31	0.149903	8.63004	CL	vs ALPHA
◇	RUN140	31	0.1499	14.7607	CL_UN	vs ALPHA_UN
◇	RUN140	31	0.1499	14.7607	CL	vs ALPHA



Full-Span Landing, Configuration 31
Slat $ds=30$ deg, $gs/c=0.015$, $hs/c=0.015$
Flap $df=30$ deg, $gf/c=0.010$, $of/c=0.005$

	Run	CONF	MMODREF	RNMODREF		
○	RUN137	31	0.150918	3.60029	CPM_UN	vs ALPHA_UN
○	RUN137	31	0.150918	3.60029	CPM	vs ALPHA
□	RUN138	31	0.149903	8.63004	CPM_UN	vs ALPHA_UN
□	RUN138	31	0.149903	8.63004	CPM	vs ALPHA
◇	RUN140	31	0.1499	14.7607	CPM_UN	vs ALPHA_UN
◇	RUN140	31	0.1499	14.7607	CPM	vs ALPHA



Full-Span Landing, Configuration 31
Slat ds=30 deg, gs/c=0.015, hs/c=0.015
Flap df=30 deg, gf/c=0.010, of/c=0.005

